PRISMIQ MediaPlayer Wireless Keyboard

P•R•I•S•M•I•Q
delivering the full spectrum of networked entertainment

You can use the wireless keyboard just like the remote control to operate your PRISMIQ MediaPlayer. Plus, it lets you easily enter text using a standard keyboard layout.

STOP
- Stops playback of a video or audio file.

PAUSE / PLAY
- Pauses or starts/resumes playback of a video or audio file.

FAST FORWARD
- Moves you forward in a video or audio file.

NEXT
- Goes to the next video or audio file in a playlist.

FULL SCREEN
- Toggles between full screen and small screen modes.
- When viewing an image full screen, use to get back to thumbnail view.

POWER
- Press this button to put the MediaPlayer in/out of sleep mode.

HOME
- Takes you to the Home screen (main screen).

DIRECTIONAL PAD
- Allows you to move the cursor up, down, left, and right on a screen.
- When viewing an image full-screen, use to move back or forward

VOLUME CONTROLS
- Volume buttons control your MediaPlayer volume only. Your TV volume is controlled with your TV remote.

SELECT
- Selects an item you've highlighted on the screen.
- When in the Images thumbnail mode, use to select an image for full-screen viewing.

BACK
- Takes you to the last screen visited (Web only).

REFRESH
- Refreshes Web pages you are viewing.

VIDEO
- Takes you to the Video screen.

AUDIO
- Takes you to the Audio screen (which includes Internet Radio).

IMAGES
- Takes you to the Images screen.

WEB
- Takes you to the PRISMIQ Web browser screen.

CHAT
- Takes you to the Chat screen.

PREVIOUS
- Goes back to the previous video or audio file in a playlist

REWIND
- Moves you backward in a video or audio file.

PAGE + -
- Scrolls up or down one screen in a list of video or audio files, on a Web page, or when viewing a news story.